

**Column Cut out Switches**  
The column cut out switches contain a set of cam-operated switches. When the control column moves in the opposite direction from the stabilizer trim direction, electric trim stops.

